

Technical Description

Carbon Filter Change

Carbon Filter comes with 4 Basic Components

1 - Top Cover

This can be detached and used as the main access point for changing the activated carbon. It also seals filter to prevent leaking. **Note: All Carbon Filters have a 2 year shelf life, but keep in mind that once removed from its package the activated carbon starts to absorb ambient air.**

2 - Cover Screws

The Cover Screws are used to seal the top cover and need to be removed to replace the used carbon.

3 - Outer Sheath

This is where air is returned into the atmosphere

4 - Activated Carbon

The activated carbon comes shipped in granulate form. Replacement carbon can be purchased through a local carbon dealer.

Replacing the Carbon

The filter is not designed to be cleaned. To change out the used activated carbon, just remove the cover screws on the top cover. Unseal the filter and remove loose carbon. This should be disposed of accordingly.

IMPORTANT! Disconnect the main power supply when changing the filter

Lifetime of the filter is determined by several factors, usage, contaminants being filtered, concentration of contaminant, and surrounding environmental factors. Normal filter lifetime should be several months.

When you begin to notice a loss of airflow or an odor, filter should be changed.

